

Top hat installation - Robin DL7 F

Disconnect the fixture from mains before installing the top hat!

Top hat DL7F Narrow (P/N 10980297)

1. Place the top hat (2) on the front lens holder (1) and tighten the four fastening Allen head bolts (3) using an Allen key 3.
2. Check, that all screws are fully tightened.

